

## EE359 – Lecture 7 Outline

- Announcements:
  - Makeup lecture this Friday, 12-1:10, Hewlett 102 (w/pizza)
  - I will have an extra OH Friday 2-3 and by appt.
  - Next HW posted today, due 10/14 5pm (ext. to 10/19 by rqst)
- Wideband Channels
- Scattering Functions
- Multipath Intensity Profile
- Doppler Power Spectrum

## Review of Last Lecture


- Signal Envelope Distribution
  - LLN leads to Rayleigh distribution (exponential power)
  - Ricean distribution when LOS component present
  - Measurements support Nakagami distribution
    - Will be useful in later BER and diversity calculations
- How long signal stays below target R (SNR  $\gamma$ )
  - Derived from level crossing rate of fading process
  - For Rayleigh fading

$$\bar{t}_R = (e^{\rho^2} - 1) / (\rho f_D \sqrt{2\pi})$$

## Review Continued: Markov Models for Fading


- Model for fading dynamics
  - Simplifies performance analysis
- Divides range of fading power into discrete regions  $R_j = \{\gamma: A_j \leq \gamma < A_{j+1}\}$ 
  - $A_j$ s and # of regions are functions of model
- Transition probabilities ( $L_j$  is LCR at  $A_j$ ):

$$p_{j,j+1} = \frac{L_{j+1}T}{\pi_j}, p_{j,j-1} = \frac{L_j T}{\pi_j}, p_{j,j} = 1 - p_{j,j+1} - p_{j,j-1}$$



## Wideband Channels

- Individual multipath components resolvable
- True when time difference between components exceeds signal bandwidth



## Scattering Function


- Fourier transform of  $c(\tau, t)$  relative to  $t$
- Typically characterize its statistics, since  $c(\tau, t)$  is different in different environments
- Underlying process WSS and Gaussian, so only characterize mean (0) and correlation
- Autocorrelation is  $A_c(\tau_1, \tau_2, \Delta t) = A_c(\tau, \Delta t)$
- Statistical scattering function:

$$S(\tau, \rho) = F_{\Delta t}[A_c(\tau, \Delta t)]$$

A 2D plot of the scattering function  $S(\tau, \rho)$  showing its dependence on delay  $\tau$  and Doppler frequency  $\rho$ .

## Multipath Intensity Profile

- Defined as  $A_c(\tau, \Delta t=0) = A_c(\tau)$ 
  - Determines average ( $T_M$ ) and rms ( $\sigma_\tau$ ) delay spread
  - Approximate max delay of significant m.p.
- Coherence bandwidth  $B_c = 1/T_M$ 
  - Maximum frequency over which  $A_c(\Delta f) = F[A_c(\tau)] > 0$
  - $A_c(\Delta f) = 0$  implies signals separated in frequency by  $\Delta f$  will be uncorrelated after passing through channel




## Doppler Power Spectrum

- $S_c(\rho) = F[A_c(\tau=0, \Delta t)] = F[A_c(\Delta t)]$

- Doppler spread  $B_d$  is maximum doppler for which  $S_c(\rho) > 0$ .

- Coherence time  $T_c = 1/B_d$

- Maximum time over which  $A_c(\Delta t) > 0$
- $A_c(\Delta t) = 0$  implies signals separated in time by  $\Delta t$  will be uncorrelated after passing through channel



## Main Points

- Scattering function characterizes rms delay and Doppler spread. Key parameters for system design.
- Delay spread defines maximum delay of significant multipath components. Inverse is coherence bandwidth of channel
- Doppler spread defines maximum nonzero doppler, its inverse is coherence time