

OCT 26, 2009

ASSIGNMENT

HW 5 DUE WEDNESDAY

NEXT ASSIGNMENT: PROJECT TOPICS

TODAY

RF PULSE DESIGN WITH SLR

DESIGNING  $B_N(z)$

SOLVING FOR  $A_N(z)$


EXAMPLES

TYPES OF  $B_N(z)$  DESIGNS

# RF PULSE DESIGN WITH SLR


## BASIC ALGORITHM (( $\pi/2$ )<sub>x</sub> PULSE EXAMPLE)

- 1) CHOOSE A FLIP ANGLE PROFILE AS A FUNCTION OF SPACE




IDEAL  
FLIP-ANGLE  
PROFILE  
EXCITATION  
EXAMPLE

- 2) COMPUTE IDEAL  $\beta(x) = \sin \Theta(x)/2$



IDEAL  $\beta$   
PROFILE

- 3) APPROXIMATE IDEAL  $\beta$  WITH  $B_N(e^{i\delta G x \Delta t})$



$$B_N(z) \Big|_{z=e^{i\delta G x \Delta t}}$$


LOW PASS DISCRETE-TIME FILTER

SAMPLED SMALL-FLIP-ANGLE FOURIER DESIGN  
RF PULSE (WINDOWED SINC)


4) USE THE MAGNITUDE CONSTRAINT

$$|A_N(z)|^2 + |B_N(z)|^2 = 1 \quad z = e^{i\omega} \text{ (not)}$$

TO SOLVE FOR  $|A_N(z)| = \sqrt{1 - |B_N(z)|^2}$



5) SOLVE FOR THE PHASE OF  $A_N(z)$ , AND HENCE  $A_N(z)$



$A_N(z)$  NOT UNIQUE

MOST USEFUL SOLUTION:

MINIMUM PHASE  $A_N(z)$

EASY TO COMPUTE

MINIMUM INTEGRATED POWER

6) USE INVERSE SLR RECURSION TO PRODUCE  
RIF PULSE

## MINIMUM PHASE $A_N(z)$

WRITE

$$A_N(z) = |A_N(z)| e^{i \angle A_N(z)}$$

COMPLEX LOGARITHM IS

$$\log A_N(z) = \log |A_N(z)| + i \angle A_N(z)$$

IF  $A_N(z)$  IS MINIMUM PHASE, NO ZEROS OR POLES ON OR OUTSIDE UNIT CIRCLE, THEN

$$\log A_N(z)$$

IS AN ANALYTIC SIGNAL (ZERO FOR NEGATIVE TIME, THE OTHER DOMAIN)

IN THIS CASE


$$\angle A_N(z) = \mathcal{H}\{\log |A_N(z)|\}$$

WHICH WE CAN COMPUTE DIRECTLY. THEN

$$A_N(z) = |A_N(z)| e^{i \mathcal{H}\{\log |A_N(z)|\}}$$

## EASIER APPROACH

GENERATE ANALYTIC SIGNAL DIRECTLY



THEN

$$\log A_N(z) = \text{DFT}\{z \hat{a}_n u(n)\}$$

AND

$$A_N(z) = e^{\log A_N(z)} \quad (\text{COMPLEX})$$

## PRACTICAL ISSUES

1) EVEN THOUGH  $A_N(z)$  IS FINITE ORDER,  $\{\tilde{a}_n\}$  IS NOT. THE LOGARITHM IS NON-LINEAR. EVALUATE  $\{\tilde{a}_n\}$  AT SOME HIGHER ORDER.

2)  $|A_N(z)|$  MUST BE POSITIVE! NO ZEROS ON UNIT CIRCLE, OR LOG BLOWS UP


$|B_N(z)|$  MUST BE LESS THAN 1

3) THE HILBERT TRANSFORM IS PERFORMED DISCRETELY. THE ORIGIN IS A SPECIAL CASE. TO COMPUTE ANALYTIC SIGNAL

1) DOUBLE POSITIVE TIME SAMPLES

2) KEEP  $n=0$  SAMPLE

3) ZERO NEGATIVE SAMPLES



ANOTHER USEFUL PROPERTY OF MINIMUM  
PHASE SIGNALS:

IF  $h_{min}(n)$  IS A MINIMUM PHASE SIGNAL,  
AND  $h(n)$  IS ANY OTHER SIGNAL WITH THE  
SAME MAGNITUDE SPECTRUM  $|H(z)|$  AND ANOTHER  
PHASE SPECTRUM  $\angle H(z)$ , THE ENERGY IN  
THE MINIMUM PHASE SIGNAL IS MORE  
CONCENTRATED NEAR THE ORIGIN

$$\sum_{n=0}^m |h(n)|^2 \leq \sum_{n=0}^m |h_{min}(n)|^2 \quad \text{FOR ALL } m$$

IN PARTICULAR

$$|h(0)|^2 \leq |h_{min}(0)|^2$$

$$|h(0)| \leq |h_{min}(0)|$$

THE MINIMUM PHASE SIGNAL HAS THE  
LARGEST VALUE AT  $n=0$ .

## MINIMUM REF POWER

MINIMUM PHASE  $A_N(z)$  HAS THE LARGEST  
CONSTANT COEFFICIENT  $A_{N,0}$ .

THE FORWARD RECURSION IS

$$\begin{pmatrix} A_j(z) \\ B_j(z) \end{pmatrix} = \begin{pmatrix} L_j & -s_j^* z^{-1} \\ s_j & C_j z^{-1} \end{pmatrix} \begin{pmatrix} A_{j-1}(z) \\ B_{j-1}(z) \end{pmatrix}$$

THE CONSTANT COEFFICIENT IS THEN

$$A_{N,0} = C_N C_{N-1} \dots C_2 C_1$$

FOR SMALL INCREMENTAL TIP ANGLES

$$\begin{aligned} C_j &= \cos \theta_j / 2 \approx 1 - \frac{1}{2} \left( \frac{\theta_j}{2} \right)^2 \\ &= 1 - \frac{1}{8} \theta_j^2 \end{aligned}$$

THEN

$$\begin{aligned} A_{N,0} &= \left( 1 - \frac{1}{8} \theta_N^2 \right) \left( 1 - \frac{1}{8} \theta_{N-1}^2 \right) \dots \left( 1 - \frac{1}{8} \theta_2^2 \right) \left( 1 - \frac{1}{8} \theta_1^2 \right) \\ &= 1 - \frac{1}{8} \sum_{i=0}^N \theta_n^2 + \dots \\ &\sim \frac{1}{N} \end{aligned}$$

HIGHER ORDER  
TERMS  
 $\sim \frac{1}{N^2}$  AND FASTER

(7)

RECALL

$$\theta_j = \gamma |B_{1,j}| \Delta t$$

SO

$$A_{N,0} = 1 - \frac{1}{8} (\gamma \Delta t)^2 \underbrace{\sum_{j=0}^N |B_{1,j}|^2}_{\text{RF POWER}}$$

LARGEST  $A_{N,0}$  MEANS SMALLEST RF POWER

MINIMUM PHASE  $A_N(z)$  GIVES MINIMUM  
POWER  $|B_1(z)|$

ALMOST ALWAYS WHAT YOU WANT

PULSE DESIGN IS DETERMINED BY  $|B_N(z)|$

$A_N(z)$  IS CHOSEN TO BE CONSISTENT,  
MINIMUM POWER







EXCEPTION SELF REFocusing PULSES

PHASE ADDED TO  $\alpha$  SO THAT

$$z \alpha^* \beta$$







HAS ENOUGH PHASE TO SHIFT THE  
ECHO TO THE END OF THE PULSE  
OR BEYOND. VERY EXPENSIVE IN RF POWER!

# SLR Excitation Pulse Design






10

# SLR Spin-Echo Pulse Design



# SLR Spin-Echo Pulse Design



## TYPES OF $B_N(z)$ DESIGNS


MANY DIFFERENT OPTIONS FOR  $B_N(z)$

LINEAR PHASE: MOST COMMON

PERFECTLY REFOCUSED WITH GRADIENT REVERSAL  
AS AN EXCITATION PULSE

SPIN ECHO PULSES

SYMMETRIC IN TIME




ALSO MAXIMUM PEAK POWER  
(PERFECTLY REPHASES!)

NOT THE MOST SELECTIVE

MINIMUM PHASE SAT PULSES AND INVERSIONS

THE FLIP OCCURS AS LATE IN THE  
PULSE AS POSSIBLE




MOST SELECTIVE PULSES

DOES NOT PERFECTLY REFOCUS

ALMOST THE SAME PEAK POWER AS  
LINEAR PHASE


MAXIMUM PHASE SATURATION AND INVERSION

MINIMUM PHASE PULSE REVERSED



QUADRATIC OR NONLINEAR PHASE

SPREADS  $P_{\text{E}}$  POWER OUT



IDENTICAL TOTAL POWER AS MIN/MAX  
PHASE PULSE WITH SAME PROFILE

MUCH LOWER PEAK POWER